

ShoreTel 110 IP Phone Quick Reference

PHONE OPERATION

Place Calls

Place a Call

Make a Conference Call

Use the Intercom

Redial Last Number

Dial Paging Extension

lift handset + access code + number

while in a call + + ext. +

lift handset + + ext.

lift handset +

number provided by administrator

lift handset

Answer Calls

Answer Call Waiting

Interact with Calls

Adjust Handset, Headset

Volume

Volume to select

Mute a Call

Mute

Place a Call On or Off Hold

Hold

Transfer a Call

Transfer + ext. + hang up

VOICE MAIL

Log Into Main Menu

lift handset + + password +

Log In from Another Extension

+ ext. + password +

Note: For more information about voice mail features, please consult the Voice Mail Quick Reference.

OFFICE ANYWHERE CODES

Transfer a call

+ destination +

Conference a call

+ destination +

Hold a call

Hang up

Access other star codes

+ (star code from below)

QUICK REFERENCE OF COMMON STAR CODES

Park a call

1 1 + ext.

UnPark a call

1 2 + ext.

Pick Up a Remote Extension

1 3 + ext.

Pick Up the Night Bell

1 4 + ext.

Use the Intercom

1 5 + ext.

Barge In

1 6 + ext.

Silent Monitor

1 7 + ext.

Toggle the Hunt Group Status

1 8 + HG ext.

Whisper Page

1 9 + ext.

Change CHM and Forwarding

Voice Mail + password + + 7 2

Change Extension Assignment

Voice Mail + password + + 7 3 1

Unassign Extension Assignment

Voice Mail + password + + 7 3 2

Assign Extension to External Number

Voice Mail + password + + 7 3 3

TROUBLESHOOTING

View Phone Information

Mute + I-N-F-O +


Reboot Your Phone

Mute + R-E-S-E-T +

Note: For additional details on the information contained in this Quick Reference card, please consult the IP 110 User Guide.

ShoreTel 110 IP Phone Quick Reference

Handset with Finger Rest



Indicator LED


Flashing light alerts the user to incoming calls and unheard voice messages.

LCD Display 1 x 16 characters





Function Keys

Perform core telephony functions (Transfer, Conference, Intercom, Redial, Voice Mail, Hold)



Function Keys Overlay

Vinyl overlay imprinted with international symbols.



Speaker


Provides audible alert for incoming calls and also provides audio for receiving inbound intercom calls.

Audio Control Keys

Mute key illuminates when active. Volume button controls handset, speaker, and ring volume.

Dial Pad

110 IP Phone with Third-Party Headset



To use a headset:

Connect a supported headset into the handset jack. Contact your system administrator for details.

NOTE: The IP110 is not a speakerphone, there is no external microphone.